

Tech tip „correct mixing“ (the SIP measuring cup)

The mixing ratio of a Vespa of 1:50 corresponds to 2% of the content of the tank. Generally, we always work on the basis of a 5 litre tank in this calculation. In this way, 100ml of engine oil is required to fill a 5 litre tank. If there is too little oil, the engine is poorly lubricated, if there is too much oil, you will not only see a small blue cloud in your wake, but above all, your engine will be cooled less efficiently, the spark plug will oil and the exhaust gets choked up. The outdated point of view that more oil equals better lubrication comes from a time in which oils were not yet manufactured according to the high standards which are normal today. „More is more“ is not the case here. For easy dosing of the mixing ratio, we recommend our SIP measuring cup with varying scale display for 1:50 and 1:25 ratios. The filling amount display, the small size and the screw top make the SIP measuring cup a must-have for your glovebox!

