

**Removal of front shock absorber on smallframe**

Put the scooter in a stable position. Remove the front wheel. Remove the swing-arm cover.



Remove the shock absorber nuts and swing-arm bolts.



Remove the base plate for the swing-arm cover and the ring washers.



Open the top nut on the shock absorber with the 13mm open spanner.



Remove the nut, star washer, ring washer and silent rubber



Push out the swing-arm and remove the shock absorber. The fitting procedure is the same only in reverse order