



# TO OPERATE THE FLASHING LIGHTS

under the chair,  
near the lever action of the piston,  
there is the button activation of  
the emergency flashers





In to the Vespa® hornrest  
is hosted the 6Volts  
battery for a Flashing  
Lights.

Is held by a  
**grab bar.**



**Battery  
access**

Movement  
for removed  
and rearmed



**instructions**

*hel & hel*